

### **Applying your “Dare to be Different” transfer**

- Arrange garment on ironing board. If garment is arranged so that front and back are 'stacked' (such as T-shirt placed on ironing board with both front and back as two layers), then insert a clean tea towel or similar between layers...this will prevent adhesive from going through front layer and bonding to back.
- Peel off backing of Transfer. The 'Tacky Tape' of the transfer is very sticky, so place transfer carefully where you want it (you will not be able to move the rhinestones once they are heat bonded to fabric!
- Cover the transfer with a clean tea towel or ironing cloth.
- Apply heat by lowering iron straight down on transfer area and push hard for 25-30 seconds. DO NOT move iron around! You will move the rhinestones from where they should be.
- Remove iron/open heat press, allow to cool for about 5-10 seconds, then remove Tacky Tape. (do not allow Tacky Tape to remain on area, remove when still warm to touch). The rhinestones will remain on garment. The Tacky Tape may pull up nap which is visible, but you can re-iron and this will disappear.
- Test stones by gently picking at them. They should be well attached. Do not try to pull them off with too much picking! You will succeed!